


LA-F2 User Manual and Program Version Cross-Reference Table

Method to Check the Program Version



- STEP1: Press and hold the .
 STEP2: Press the to enter the Information Interface.
 STEP3: Display the program version in the bottom right corner of the interface.

Program Version	User Manual
V2.0.2~V2.1.4.F	LA-F2 V2.0 User Manual Rev00(program version:V2.0.2~V2.1.4.F)

* Explanation:
 Machine Model + Mechanical Version + User Manual + Manual Version (Program Version)